Mode	Number	Name	Drawbars	AF1=Perc	AF2=Chorus	Notes
Voice	89	000000888 Rotary 1				
Voice	90	608000000 Rot1 AF2Ch			Yes	
Voice	91	Even Bars Rotor 1				
Voice	92	Odd Bars Rotor 1				
Voice	93	888800000 Ro1 AF2Ch			Yes	
Voice	94	Jazz Rotor 1 AF2=Ch			Yes	
Voice	95	888000000 Rotary 1				
Voice	96	688000000 Rotary 1				
Voice	97	Percussion AF1 Rot 1		Single Trig.		Sounds only with AF1
Voice	98	Leakage Rotary 1				
Voice	99	Dbar1 Rotary2 AF2=Ch			Yes	
Voice	100	Dbar2 Rotary2 AF2=Ch			Yes	
Voice	101	Dbar3 Rotary2 AF2=Ch			Yes	
Voice	102	Dbar4 Rotary2 AF2=Ch			Yes	
Voice	103	Dbar5 Rotary2 AF2=Ch			Yes	
Voice	104	Dbar6 Rotary2 AF2=Ch			Yes	
Voice	105	Dbar7 Rotary2 AF2=Ch			Yes	
Voice	106	Dbar8 Rotary2			Yes	
Voice	107	Dbar9 Rotary2			Yes	
Voice	108	808000000a Ro2 AF2Ch			Yes	
Voice	109	808000000b Ro2 AF2Ch			Yes	
Voice	110	804000000 Rot2 AF2Ch			Yes	
Voice	111	408000000 Rot2 AF2Ch			Yes	
Voice	112	080800000a Ro2 AF2Ch			Yes	
Voice	113	080800000b Ro2 AF2Ch			Yes	
Voice	114	080400000 Rot2 AF2Ch			Yes	
Voice	115	000088000 Rot2 AF2Ch			Yes	
Voice	116	000084000 Rot2 AF2Ch			Yes	
Voice	117	000000808 Rot2 AF2Ch			Yes	
Voice	118	000000088 Rotary 2				
Voice	119	000000888 Rotary 2				
Voice	120	608000000 Rot2 AF2Ch			Yes	
Voice	121	Even Bars Rotor 2				
Voice	122	Odd Bars Rotor 2				
Voice	123	888800000 Ro2 AF2Ch			Yes	
Voice	124	Jazz Rotor 2 AF2=Ch			Yes	
Voice	125	888000000 Rotary 2				
Voice	126	688000000 Rotary 2				
Voice	127	Percussion AF1 Rot 2		Single Trig.		Sounds only with AF1
Voice	128	Leakage Rotary 2				